



Connect Crossing System



Installation Guide

Tel.+44 (0)1422 839610

E-mail. sales@rosehillrail.com

Version : 23.10 V7.0


rosehillrail.com




RODDED COMPONENTS LIST.

12

PANELS



END RESTRAINT & RAIL CLAMP KIT



MOVEMENT RESTRICTOR





CHAIN GUARD

FIXING BOLTS WITH WASHERS ASSEMBLED


(CHAIN GUARD & PANELS)

Copper Grease required and supplied

H1






10



EDGE BEAMS




RUBBER & CONNECTING PLATE

STEEL 250 X 250



RUBBER PLUG

COVER PLATE



WOOD SCREW

LIFTING PIN KIT


TOOL KIT (OPTIONAL)




27AF

27AF


11




1




2




8b




9b




8a




3



9a




4A




4B




Apply copper grease to each bolt assembly




4C



7A




7B



RUBBER EDGE BEAMS ON CONCRETE SILL BEAMS, SET ON COMPACTED CONCRETE BED & SUB-BASE AS SPECIFIED BY CLIENTS OR INSTALLERS CIVIL ENGINEER.

6



5 

